

Section C

Heating, Ventilation and Air Conditioning (HVAC)

This Section Refers to Cars from

**Chassis (VIN) SCAZSOOOOACH01001
to Chassis 16930.**

1980 to September 1986

Discrete Component Controlled Climate Control

Issue record sheet 1

March 1984

The dates quoted below refer to the issue date of individual pages within this chapter.

Sections	C1	C2	C3	C4	C5	C6	C7	C8	C9	C10
Page No.										
Contents						Mar 84				
1	Jan 81	Jan 81	Jan 81			Jan 81	Apr 81	Apr 81	Apr 81	
2			Jan 81			Jan 81				
3		Jan 81	Jan 81			Jan 81	Apr 81			
4		Jan 81				Jan 81	Apr 81			
5		Jan 81				Jan 81	Apr 81			
6						Jan 81	Apr 81			
7						Jan 81	Apr 81			
8							Apr 81			
9						Jan 81	Apr 81			
10							Apr 81			
11						Mar 84	Apr 81			
12							Apr 81			
13						Mar 84	Apr 81			
14							Apr 81			
15							Apr 81			
16							Apr 81			
17							Apr 81			
18							Apr 81			
19							Apr 81			
20										
21										
22										
23										
24										
25										
26										
27										
28										
29										
30										
31										
32										
33										
34										
35										
36										
37										
38										
39										
40										
41										
42										
43										
44										
45										
46										
47										
48										

TSD 4400

Air conditioning system

Contents	Sections			
	Silver Spirit Mulsanne	Silver Spur	Mulsanne Turbo	Corniche
Precautions	C1	C1	C1	C1
Introduction and basic operation	C2	C2	C2	C2
Component description	C3	C3	C3	C3
Detailed circuit description	C4	C4	C4	C4
System test and fault diagnosis	C5	C5	C5	C5
Refrigeration system	C6	C6	C6	C6
Component removal and assembly	C7	C7	C7	C7
Torque tightening figures	C8	C8	C8	C8
Workshop tools	C9	C9	C9	C9

Chapter C

Issue record sheet 2

March 1984

The dates quoted below refer to the issue date of individual pages within this chapter.

Section	C1	C2	C3	C4	C5	C6	C7							
Page No.														
49							Sept 78							
50							Sept 78							
51							Sept 78							
52							Sept 78							
53							Dec 78							
54							Dec 78							
55							Sept 82							
56							Sept 82							
57							Dec 78							
58							Dec 78							
59							Mar 84							
60							Mar 84							
61							Dec 78							
62							Dec 78							
63							Dec 78							
64							Dec 78							
65							Dec 78							
66							Dec 78							
67							Dec 78							
68							Dec 78							
69							Dec 78							
70							Dec 78							
71							Dec 78							
72							Dec 78							
73							Dec 78							
74														
75														
76														
77														
78														
79														
80														
81														
82														
83														
84														
85														
86														
87														
88														
89														
90														
91														
92														
93														
94														
95														
96														

Precautions

Danger — Exhaust gases

Sitting in a car that is in a confined space with the engine running is dangerous. Operating the air conditioning unit will increase this danger.

First aid — Refrigerant burns

If the skin is injured by refrigerant it should be bathed with clean cold water and medical attention sought immediately. Do not apply any localised heat or hot dressings, etc.

An eye injured by refrigerant must be immediately washed with clean cold water. The eye must not be rubbed as this will aggravate the injury.

A doctor should be consulted as soon as possible after administering emergency treatment.

General precautions

Before commencing work on the electrical system or components it is recommended that the battery master switch (situated in the luggage compartment) be turned off.

If the battery has to be left connected for any reason the gear range selector lever must be placed in the Park position and the gearchange isolator and ignition key removed.

The battery master switch must not be operated whilst the engine is running.

Short circuiting or reverse polarity will cause immediate and permanent damage to the electronic components.

It is important that no 'live' connections or disconnections are made where fuel vapour or other inflammable materials are present.

Where reference is made in this Chapter to the use of voltmeters or continuity testers never use generator type meters.


Section C2

Refrigeration unit Contents

Description	Page
Refrigeration - special precautions and accident damage	C2 - 3
Handling the refrigerant	C2 - 3
Accident damage	C2 - 4
Chemical stability of refrigerant	C2 - 4
Servicing the refrigeration system	
Refrigeration system - To discharge, purge or drain	C2 - 5
Refrigeration system - To evacuate	C2 - 5
Refrigeration system - To sweep	C2 - 6
Refrigeration system - To charge	C2 - 6
Oil level - refrigeration system	C2 - 7
Replacing components	C2 - 7
Low refrigerant charge protector system	C2 - 7

Air conditioning system heater and control box

Figure C2-1



Introduction and basic operation

Introduction

The basic function of the air conditioning system is to automatically maintain selected temperatures of the upper and lower levels of the car interior, regardless of climatic conditions.

Basic operation (see fig. C2-3)

One of the features of the air conditioning system is that all air entering the system is dehumidified and cooled. This is done by passing the air through the refrigeration evaporator matrix before it enters the heater and control box assembly.

The upper and lower systems operate independently, each system having its own air temperature sensor chain, temperature selector, servo mechanism, blend flap and electronic circuitry.

The heater and control box supplies hot and cold air to the two independent ducting systems. The upper system delivers air to the windscreen demister outlets, circular facia outlets and the rectangular facia outlet. The lower system delivers air to the lower outlets in both the front and rear compartments of the car.

Fig. C2-1 Air conditioning system heater and control box

- 1 Circular facia outlet (1 of 2)
- 2 Windscreen demister outlet
- 3 Upper system air blend flap (1 of 2)
- 4 Solar sensor
- 5 Heater box
- 6 Heater matrix
- 7 Ambient air intake
- 8 Refrigeration matrix
- 9 Windscreen/facia mode change actuator
- 10 Lower quantity flap micro-switch
- 11 Lower quantity flap actuator
- 12 Recirculation actuator (1 of 2)
- 13 Fan motor (1 of 2)
- 14 Recirculation flap (1 of 2)
- 15 Fan speed module and voltage stabilizer
- 16 Air conditioning diode board
- 17 Lower quantity footwell outlet
- 18 Lower quantity flap
- 19 Lower system air blend flap
- 20 Windscreen/facia mode change flap
- 21 Upper system servo module
- 22 Servo assembly
- 23 Upper servo trimming potentiometer
- 24 Servo assembly test socket
- 25 Lower servo trimming potentiometer
- 26 Lower system servo module
- 27 Rectangular facia outlet
- 28 Rectangular facia outlet control flap




Fig. C2-2 Air conditioning control panel

- 1 Upper system override (AUTO/FACIA) switch
- 2 Upper temperature selector (optimum setting)
- 3 Lower temperature selector (optimum setting)
- 4 Air conditioner control (function) switch

Contained in each ducting system is an air temperature blend flap. The position of which determines the ratio of hot and cold air required to achieve the pre-selected temperatures. The blend flaps form the basis of the air conditioning system, each flap being operated by an electro-mechanical servo controlled by its servo module (see fig. C2-1).

Each servo module collects information in the form of temperature related current signals provided by temperature sensors from various parts of the car. The module then compares actual in-car air temperature with the pre-selected required temperature and then operates the servo to position the air temperature blend flap. This achieves the required in-car temperature.

The air conditioning system also includes a coolant tap (mechanically operated in conjunction with the lower servo mechanism), two air recirculation flaps, a windscreen/facia mode change flap and a lower air quantity flap. These are operated by electrical actuators upon signals related to servo positions.

A rear window demister is incorporated into the system. The demister element is automatically switched on whenever the car is being heated, this being the only time that misting or ice formation is likely to occur.

Two fans, controlled by an electronic fan speed control unit, are used to boost the input of air to the system.

Driver's controls

The driver's controls comprise four switches situated on the air conditioning control panel (see fig. C2-2). Also three manually operated air flow controls situated on the facia.

The function and operation of these controls is as follows.

Air conditioner (function) control (see fig. C2-2)

The air conditioner (function) control is a five position rotary switch marked OFF, LOW, AUTO (automatic), HIGH and  (defrost).

The function of the air conditioning system in each switch position is as follows.

OFF The air conditioning system is switched off and ambient air is prevented from entering the car as the recirculation flaps will be in the recirculation position.

Turning the function switch to OFF from any other position immobilises all flaps other than the recirculation flaps, which if not already in the recirculation position will move to that position.

The fan motors are also switched off.

LOW The system provides automatic air temperature control with the fan motors running at a fixed low speed.

AUTO The system provides automatic air temperature control. The fan speed automatically varies in relation to servo position. Maximum fan speed is not attainable in this position.

HIGH The system provides automatic air temperature control. The fan speed automatically varies in relation to servo position. Maximum fan speed is attainable

(defrost). The system shuts off the supply of air to the lower outlets and all available heat is directed to the windscreen outlets.

The fan motors operate at maximum speed even if the engine coolant is cold and heated air is not available.

Temperature selector controls (see fig. C2-2)

Any in-car air temperature between 17°C and 33°C can be independently selected for the upper and lower levels of the car interior using the UPPER TEMPERATURE and LOWER TEMPERATURE selectors respectively. The selected temperatures will then be automatically maintained within the limitations of the system.

Upper system override (AUTO/FACIA) switch (see fig. C2-2)

When the air conditioning system is functioning automatically and air is being directed to the windscreen demister outlets the driver may, if he prefers, direct the air to the facia outlets by momentarily pressing the override switch to the FACIA position.

To cancel the override facility and return the system to automatic control, press the switch to the AUTO position.

The override facility will also be cancelled when the ignition is switched off.

Manually operated flap controls (see fig. C2-1)

Three manually operated controls are provided to direct and regulate the flow of air from the upper system facia outlets.

When the system is providing air to the facia outlets the two circular outlets can be swivelled to direct the flow of air as required. The rectangular facia outlet admits air into the car when the flap control lever is pressed down.

Fig. C2-3 Airflow and system control

- | | |
|----|---|
| 1 | Solar sensor |
| 2 | Cantrail sensor |
| 3 | Upper system ambient sensor |
| 4 | Servo assembly |
| 5 | Air conditioning control panel |
| 6 | Lower system ambient sensor |
| 7 | Knee roll sensor |
| 8 | Fan speed module and voltage stabilizer |
| 9 | Windscreen demister outlets |
| 10 | Windscreen/facia mode change flap |
| 11 | Circular facia outlets |
| 12 | Rectangular facia outlet |
| 13 | Lower system footwell outlets |
| 14 | Lower quantity flap |
| 15 | Coolant tap |
| 16 | Recirculation flaps |
| 17 | Fan motors |
| 18 | Ambient air intakes |
| 19 | Refrigeration matrix |
| 20 | Heater matrix |
| 21 | Upper system air blend flap |
| 22 | Lower system air blend flap |
| A | Lower sensor chain |
| B | Upper sensor chain |
| C | Ambient air |
| D | Recirculated air |
| E | Refrigerated air |
| F | Heated air |
| G | Warm air |

Section C2

Refrigeration unit

Description (see Fig C2)

The refrigerant (Refrigerant 12) is circulated by a compressor which is driven from the engine crankshaft by twin 'vee' belts. An electro-magnetic clutch is incorporated in the compressor that is energised in the engaged position at all times when the engine is running except when the ambient temperature is below 0°C.

High pressure vapour is pumped from the compressor to the condenser matrix where it condenses from vapour at the top of the matrix to a liquid at the bottom of the matrix. The liquid passes to a receiver/drier which absorbs any traces of moisture that may be present and it also ensures that the refrigerant passes to the expansion valve in liquid form.

A sight glass on the drier enables the refrigerant to be inspected whilst the system is operating when a steady flow of liquid should be observed. If bubbles or foam can be seen it usually indicates incorrect operation of the system or insufficient refrigerant, however it is normal for some foaming to show when the ambient air temperature is below 21 °C. The refrigerant is pumped to the expansion valve which controls the flow of refrigerant to the evaporator. To achieve this, the temperature in the evaporator outlet pipe is sensed by a phial attached to the outside of the pipe and the pressure in the pipe is sensed by an equaliser line connected to the suction throttling valve.

When the refrigerant enters the evaporator, heat is transferred from the air passing through the evaporator to the refrigerant causing the refrigerant to evaporate, thereby cooling the air.

From the evaporator, the refrigerant (which is now a low pressure vapour) passes to the suction throttling valve which 'throttles' the refrigerant flow to maintain a constant pressure within the evaporator regardless of the compressor speed or evaporator loading. The refrigerant then passes to the compressor as a low pressure vapour.

Refrigeration special precautions & accident damage**Handling the refrigerant**

The refrigerant used in the air conditioning system is dichlorodifluoromethane (internationally known as Refrigerant 12) and is usually supplied to the Service network as a liquid under pressure in either disposable containers or metal drums, dependent




Fig. C2 Refrigeration component layout

- 1 Condenser matrix
- 2 Receiver 'drier
- 3 Expansion valve
- 4 Evaporator matrix
- 5 Sensor
- 6 Suction throttling valve
- 7 Compressor

upon the quantity ordered.

If it is correctly handled the refrigerant is perfectly safe, however if incorrectly handled it can cause serious injury or damage. In particular, smoking in the region of exposed refrigerant can be



Fig. C3 Refrigerant handling - safety precautions



Fig. C4 Approved refrigerant oil

a health hazard. The following elementary safety precautions should be adopted when handling refrigerant:

1. If the drum has a metal cap, always ensure that the cap is fitted when not in use.
2. Do not carry refrigerant in the passenger compartment of a car, always place the drum in the luggage compartment.
3. If a drum is to be transported or stored, always shield it from the direct rays of the sun. (The sun's heat could increase the pressure within the drum sufficiently to activate the safety valve causing the refrigerant to escape.)
4. A drum must not be overfilled because the increased pressure can cause the drum to explode before the temperature rises to a point where the temperature safety valve is activated.
5. Do not subject the drum to high temperatures when charging the system. The drum must not be placed on a radiator or stove, neither must a blow-lamp be used for heating the drum.

To heat the drum when charging, the drum should be immersed in warm water which must not exceed 51°C.

6. Do not discharge the refrigerant where there is an exposed flame or where it can be drawn into the engine air intake. Concentrations of this refrigerant in contact with a flame can produce a poisonous gas.

7. Do not discharge the refrigerant in a confined space because it will displace the air which could result in suffocation.

8. Always wear goggles when carrying out work which involves the use of refrigerant or when opening any of the lines. If an accident occurred and refrigerant struck the face, goggles would protect the eyes and therefore reduce the risk of serious injury.

9. Excessive heat applied to any section of the refrigerant lines will create excessively high pressures, therefore welding should not be carried out on any part of the car adjacent to the refrigerant units or lines.

Accident damage (refrigerant)

It is essential that the air conditioning system is inspected as soon as possible if the car has been involved in an accident.

If the system has been 'opened' as a result of an accident, air, moisture and dirt could have entered the system causing internal damage to the components. The extent of the damage and the length of time since the damage occurred will govern the amount of work required to correct the system. A definite repair procedure cannot be recommended to cover all cases of accident damage therefore the following guidelines should be followed:

1. Ensure that the compressor clutch is disengaged if the car is to be driven before repair work is carried out. This can be achieved by disconnecting the blue/yellow cable from the compressor ambient

switch located on the engine compartment face of the evaporator box (Fig. C19)

2. Inspect all refrigeration components and lines.
3. If the condenser has been damaged it **MUST** be replaced; soldering, brazing or welding etc. must not be attempted.
4. Fit a new receiver/drier if damage has occurred or if the system has been 'open' for more than one day.
5. Check the compressor and clutch pulley for cracks, if the clutch plate is bright yellow it should be replaced.
6. If the compressor does not show signs of external damage it may be used again.

Chemical stability of the refrigerant

The efficient operation of the air conditioning system depends upon the pressure/saturation temperature relationship of the refrigerant.

Provided that the system contains pure refrigerant, plus a certain amount of refrigerant oil which mixes with the refrigerant, it is considered to be chemically stable.

However, when foreign materials such as dirt, air or moisture enters the system, the chemical stability is affected which results in a change in the pressure/saturation temperature relationship of the refrigerant. The system will then no longer operate at the correct pressures and temperatures which decreases the efficiency of the system. The following general rules should be observed to ensure chemical stability in the system.

1. Before disconnecting a refrigeration connection, wipe away all dirt or oil from the connection to prevent foreign matter entering the system.
2. All tools should be kept clean and dry.
3. Before adding oil, ensure that the container and tube (if any) is clean and dry in order to keep the refrigerant oil as free of moisture as possible.
4. Before 'opening' the refrigeration system, ensure that all tools etc. are close at hand to reduce the operation time to a minimum. Do not leave the system 'open' longer than necessary.
5. If the system has been 'opened' and sealed again, it must be correctly evacuated.

Servicing the refrigeration system

Refrigeration system - To discharge, purge or drain

1. The refrigerant must be discharged from the system before 'opening' any joint. Always wear goggles when carrying out work which involves 'opening' refrigerant lines.
2. Refrigerant must not be discharged near an open flame otherwise a poisonous gas will be formed. This also applies to discharging when smoking a cigarette or near a car engine air intake.
3. Remove the caps from the compressor discharge valve and the service connection of the suction throttling valve and attach to the manifold gauge set (with depressors fitted), after ensuring that the




Fig. C5 Manifold gauge set

The illustration shows the manifold hand valve with the suction side cracked, while high side remains closed. Pressure is recorded on both gauges even though one hand valve is cracked.

- 1 'Low' side hand valve
- 2 Connection to suction throttling valve
- 3 Charging or evacuating connection
- 4 Connection to compressor
- 5 'High' side hand valve

valves are closed. Attach a pipe to the centre connection of the gauge set.

4. Crack both hand valves and open further as the system discharges.

5. Do not release the refrigerant too quickly as this can result in oil being drawn from the system. If any trace of oil is noticed, loosen the adapter. The operation should require at least 15 minutes to ensure complete discharge.

Note

Any oil which has discharged into the container should be measured and a corresponding amount added to the system.

6. When all the refrigeration appears to have escaped, slacken the adapter to close the valve and allow approximately two minutes for any build-up of pressure in the system to develop, then repeat the discharge procedure.

This operation should be repeated until all the refrigerant has been discharged.

Refrigeration system - To evacuate

1. Ensure that the system is fully discharged.
2. Connect the centre pipe of the manifold set to the vacuum pump. The vacuum pump should have a 20-0 torr vacuum gauge fitted (1mm Hg = 1torr).
3. Open both valves on the manifold set and switch on the vacuum pump. When a reading of 5 torr or less has been obtained, allow the pump to operate for a further 15 minutes.

Note

The vacuum of 5 torr is related to sea level only.




Fig. C6 Suction throttling valve

- 1 Oil bleed line
- 2 Service valve connection
- 3 Equaliser line connection

4. Switch off the vacuum pump, if the vacuum falls quickly investigate for a leak.
5. If the system loses vacuum very slowly, a leak is possible but it is advisable to evacuate for a further 45 minutes to eliminate the possibility of residual liquid refrigerant in the compressor oil vaporising and causing the pressure to rise.
6. The final vacuum reading obtained should be held for 30 minutes to ensure that there are no leaks in the system.

Refrigeration system - To sweep

1. Evacuate the system
2. Connect the refrigerant bottle to the centre connection of the manifold set, close the low side valve (to suction throttling valve) and open the

valve on the bottle.

3. Ensure that the low pressure gauge comes out of vacuum, close the high side valve (to compressor) and open the low side valve.
4. Charge the system with 0.45 kg (1 lb) of Refrigerant 12. If the ambient temperature is low it may be necessary to start the engine and switch on the system in order to draw in the refrigerant. Run the engine for a further 10 minutes with ACU switch set to HIGH.
5. Switch the system off and stop the engine.
6. Allow 5 to 10 minutes for the refrigerant pressure to equalise.
7. Leak test the system using an electrical leak detector. If a leak is detected, it must be rectified and the discharge and evacuation operations repeated.
8. If the system maintains its pressure, discharge and evacuate the system prior to charging.

Refrigeration system - To charge

Before charging the system, it is necessary to evacuate and sweep the system.

1. Attach a cylinder of Refrigerant 12 to the appropriate connection on the vacuum pump apparatus.
2. Open the cylinder valve and purge the line between the cylinder and the vacuum pump apparatus.
3. Suspend the cylinder on a spring balance and note the weight.

Note

If a 'charging station' or other refrigeration system servicing equipment is used, follow the manufacturers instructions.

4. Open the tap on the vacuum pump apparatus to enable the refrigerant to flow into the system.
5. Ensure that the parking brake is applied and that the gear selector is in either 'Park' or 'Neutral'.
6. Start the engine and run it at 1000 to 1250 rpm.
7. Move both temperature selector dials to the 'Full cold' position. Open the circular facia outlets and the rectangular outlets; move the air conditioning function switch to HIGH.
8. Allow 0.45 kg (1 lb) of refrigerant to flow into the system, close the tap on the vacuum pump apparatus and switch off the engine.
9. Test for leaks in the system with an electrical leak detector. If the system is free of leaks, continue the charging operation and increase the weight of refrigerant in the system by 1.02 kg (2.25 lb) to make the total weight of refrigerant added equal to 1.47 kg (3.25 lb).
10. If a leak is detected it must be rectified and the evacuation and charging operation repeated.


Note

The presence of bubbles or foam passing through the receiver drier sight glass is not a reliable indication of refrigerant deficiency if the ambient temperature is below 24°C (75°F).

11. Close the tap on the vacuum apparatus and unscrew the connection to the valve of the service connection on the suction throttling valve and fit the valve cap.
12. Check the system for leaks.

Airflow and system control

Figure C2-3



Oil level - refrigeration system

The refrigeration pump is originally filled with 310ml (10.5 ounces US of 'Frigidaire' 525 viscosity refrigeration oil and servicing is not normally required. However, during normal operation, a small amount of oil combines with the refrigerant and circulates round the system.

If any oil escapes from the system due to leakage, discharge of the refrigerant or replacement of a component, it must be replaced because it is important that the amount of oil in the system is always correct.

Insufficient oil in the system will result in inadequate lubrication of the compressor and too much oil circulating with refrigerant will reduce the cooling capacity of the system.

The procedure for correcting the oil level is as follows:

1. Ensure that the parking brake is firmly applied and the transmission is in either 'neutral' or 'Park'.
 2. Run the engine at 1000 to 1500 rpm for ten minutes with the ACU temperature selector dials turned to the 'maximum cold' position and set to AUTO, this will allow the oil to be distributed throughout the system.
 3. Stop the engine, discharge the refrigerant and remove the compressor.
 4. Position the compressor horizontally with the drain plug pointing downwards.
 5. Remove the drain plug and allow the oil to drain into a clean measuring container; measure and discard the oil.
 6. If the oil drained from the compressor is more than 125 ml (4 ozs US), top-up the compressor with an equivalent amount of new compressor oil.
 7. If the oil drained from the compressor is less than 125 ml (4 ozs US) and a major oil loss has occurred, fill the compressor with 185 ml (6 ozs US) of compressor oil.
 8. If the compressor has been overhauled, increase the quantities given in the two previous paragraphs by 30 ml (1.0 oz US).
 9. If a new compressor is to be fitted, the oil contained in it should be drained into a clean measuring cylinder and the quantity adjusted until the amount is equivalent to that drained from the old compressor.
- This amount should then be poured into the new compressor, plus any oil lost during rapid discharge of the refrigerant.

Replacing components

Whenever a refrigeration system component is replaced, measured quantities of approved refrigerant oil must be added to the component to ensure that the total amount of oil in the system is maintained.

Oil should be added in the following quantities plus any lost through rapid discharge of the system:

Evaporator - 90 ml (3 ozs US)

Condenser - 30 ml (1 oz US)

Receiver/Drier - 30 ml (1 oz US)

Low refrigerant charge protector system**System description**

The low refrigerant charge protector system consists of a superheat shutoff switch located in the rear head of the compressor, connected in series by an electrical lead to the thermal fuse which is basically a temperature sensitive fuse link between the air conditioning system ambient switch and the clutch coil connection.

During normal air conditioning system operating conditions, current flows through the air conditioner switch, the ambient switch, and through the thermal fuse to the clutch coil to actuate the compressor clutch. Should a partial or total loss of refrigerant in the system cause the superheat switch to sense low system pressure and a high suction gas temperature, the superheat switch contacts will close. When the contacts close, current flows to energize the resistance type heater in the thermal fuse. The resultant heat warms the fuse link to its specific melt temperature, thus opening the circuit to the compressor clutch coil. Compressor operation ceases and compressor damage due to a loss of refrigerant charge is prevented. The cause of the refrigerant loss must be corrected and the system charged prior to replacing the thermal fuse.

Component description

Temperature sensors

The temperature sensors used in the air conditioning system are thermistors. These are devices that vary in resistance as temperature changes. As the temperature changes the amount of current flowing through the sensors varies proportionately.

The current signals emitted by the sensors are used to help determine the positions of the temperature blend flaps.

There are two sets of sensors in the air conditioning system, one set comprising three sensors is referred to as the upper sensor chain. The other set of two sensors is known as the lower sensor chain.

The function of the sensors in each chain is as follows.

Upper sensor chain

1. The solar sensor (see fig. C2-3) measures the effect of heat radiated by the sun into the car.
2. The cantrail sensor (see fig. C2-3) measures the upper level in-car temperatures.
3. The upper air ambient sensor (see fig. C2-3) measures the outside air temperature.

Lower sensor chain

1. The knee roll sensor (see fig. C2-3) measures lower level in-car temperatures.
2. The lower air ambient sensor (see fig. C2-3) measures the outside air temperature.

Servo assembly (see figs. C3-1 and C2-1)

The servos drive the air temperature blend flaps and also provide signals to activate other automatic functions within the system.

There are two servos contained within the assembly, one for the upper system and one for the lower system.

The upper servo controls the temperature and quantity of air from the windscreen and facia outlets. The lower servo controls the temperature and quantity of the air from the lower outlets.

The systems controlled by the upper servo are the recirculation actuators, lower quantity actuator, windscreen/facia mode change actuator, upper temperature blend flap, fan speed and rear window demister.

The systems controlled by the lower servo are the lower temperature blend flap, coolant tap and fan speed.

Upper and lower system servo modules (see fig. C3-1)

The movement of each servo is controlled by its servo module. Acting upon information computed from its sensor chain and temperature selector the module controls servo position.

The two servo modules are identical and therefore




Fig. C3-1 Servo assembly

- 1 Coolant tap Bowden cable
- 2 Coolant tap lower servo connection
- 3 Lower servo blend flap connecting rod
- 4 Upper servo blend flap connecting rod
- 5 Sensor chain socket
- 6 Upper servo module
- 7 Upper servo trimming potentiometer
- 8 Lower servo trimming potentiometer
- 9 Servo test socket
- 10 Lower servo module

interchangeable. However, the servos must be recalibrated if the modules are interchanged.

Fan speed module and voltage stabiliser (see fig. C2-3)

The fan speed module and voltage stabiliser are independent components assembled to form one unit.

The fan speed module provides variable fan speeds automatically controlled by servo positions. With both servos in the mid-position the fans run at minimum speed but as either or both servos move towards their 'full hot' or 'full cold' positions the fan speed increases progressively.

The voltage stabiliser provides two 7.0 volt supplies to the servo motors and a 9.1 volt supply to the servo modules. These render the servos insensitive to car system voltage variations.

Coolant tap (see fig. C6-4)

The coolant tap incorporated in the cooling system is connected to a cranked lever on the lower servo output

shaft. The tap is connected by a bowden cable. The tap opens progressively as the lower servo moves towards the hot position.




Fig. C3-2 Lower quantity and windscreen/facia mode change actuators

- 1 Windscreen/facia mode change actuator
- 2 Lower quantity flap actuator
- 3 Lower quantity flap
- 4 Lower quantity flap micro-switch
- 5 Windscreen/facia mode change flap




Fig. C3-3 Fan delay thermostat (applicable to cars conforming to a Japanese or North American specification)

Recirculation actuators and flaps (see fig. C2-1)

There are two recirculation actuator and flap assemblies incorporated into the system. The actuators operate simultaneously and each has two positions, one of which directs fresh air from outside the car into the air conditioning system; the other position recirculates air from within the car.

The actuators are activated by a micro-switch in the upper servo. This signals full recirculation when the servo is at the 'full cold' position or when the air conditioning is switched off. When the servo is at any other position than 'full cold' fresh air is signalled.

Mode change actuator and flap (see figs. C3-2 and C2-1)

The actuator operates the mode change flap to direct air to either the windscreen demister outlets or to the facia outlets.

When the upper servo is below 25% of its travel from 'full cold' towards 'full hot' the mode flap directs air to the facia outlets. Above 25% of its travel air is directed to the windscreen demister outlets. However, the upper system override (AUTO/FACIA) switch may be used to direct air to the facia outlets when the servo is above 25% of its travel.

Lower quantity actuator and flap (see figs. C3-2 and C2-1)

The lower quantity actuator operates the lower quantity flap. The flap is closed when the upper servo is below 10% of its travel from 'full cold' towards 'full hot'.

If defrost position has been selected on the air conditioning function switch the system overrides to close the lower quantity flap. This enables all available air to be directed to the upper system.

The lower quantity flap is also closed whenever the engine coolant temperature is below 44°C.

The micro-switch incorporated into the lower quantity flap linkage holds off the fan motors until the flap is fully open. This prevents a large quantity of air being suddenly directed from the windscreen area.

Fan delay thermostat (see figs. C3-3 and C3-4)

The fan delay thermostat is closed when the engine coolant temperature is below 44°C. This prevents the




Fig. C3-4 Fan delay thermostat (applicable to cars other than those conforming to a Japanese or North American specification)

fans operating and also closes the lower quantity flap.

When the engine coolant temperature reaches 44°C the thermostat opens to operate the lower quantity flap. Only when the flap is fully open does the lower quantity flap micro-switch open to allow the fans to operate.

Relays (see fig. C3-9)

The relays associated with the air conditioning system are all of the Bosch 12 volt 20/30 amp type.

With the exception of the starter relay all relays are interchangeable.




Fig. C3-5 Switching relay

- A Not energised
1 Switch open
2 Bulb not illuminated

- B Energised
1 Switch closed
2 Bulb illuminated




Fig. C3-6 Changeover relay

- A Not energised
1 Switch open
2 Bulb not illuminated
3 Bulb illuminated through the normally closed contacts of the relay

- B Energised
1 Switch closed
2 Bulb illuminated
3 Bulb not illuminated

Section C4

Interlock and Inhibit systems

Interlock (see Fig. C22)

The interlock circuit prevents the ACU from operating until the car engine is running to allow all battery power to be available to start the car during engine cranking.

Sequence of operations

1. The fan and compressor fuse supplies voltage to contact C2 of the fan and compressor relay at all times.
2. When the ignition is switched on and the ACU function switch is set to LOW, AUTO, HIGH or DEFROST, the coil of the fan and compressor relay is energised, the earth path being provided by the low resistance winding of the starter motor.
3. Contact C2 and C1 are 'made' which connects the live feed from fan and compressor relay to contact C2 of the servo isolation relay and the fan speed module.
4. The servo isolation relay coil is also energised because the oil pressure switch is closed (no oil pressure). Contact C2 is connected to C1 thereby isolating the live feed from the servos and voltage stabiliser.
5. When the starter motor is operated it effectively de-energises the coil of the fan and compressor relay, contact C1 and C2 are broken which disconnect the feed from the fan and compressor fuse. This allows all available battery power to start the car.
6. When the engine has started and the oil pressure has built up, the coil of the fan and compressor relay is again energised, remaking C1/C2 and the coil of the servo isolation relay is de-energised which connects the live feed from C2 to C3 which completes the circuit for the servos and voltage stabiliser.

Note

The fans will not operate until the fan inhibit cycle is completed.

Inhibit (see Fig. C23)

The inhibit circuit prevents the compressor and fans from operating under the following circumstances:

1. The compressor is disconnected when the ambient temperature is below 1 °C.
2. The compressor and fans are inhibited when the ACU is operating in the 'screen' mode (except when DEFROST has been selected), until the engine coolant is above 44 °C and the lower quantity flap is fully open. This prevents cold air from being blown into the car when hot air is required and also prevents a sudden surge of air to the screen causing considerable noise which, as well as being




Fig. C17 1. Fan and compressor relay
2. Fan delay relay
3. Servo isolation relay
4. Fan and compressor fuse

undesirable, would also be unexpected.

3. The fans are inhibited for 13 seconds after the starter motor has operated to allow the compressor to freeze any condensed water vapour in the system and so prevent moist air from misting the wind-screen in the screen mode.

In (1), the compressor thermostat, which is situated in the evaporator box, 'breaks' below 1 °C and disconnects the live feed from the compressor clutch thereby disconnecting the compressor.




Fig. C18 Compressor protection device

- 1 Compressor safety fuse
- 2 Compressor clutch thermostat
- 3 Compressor temperature sensor





Fig. C19 Compressor ambient thermostat

In (2), the fan speed module and compressor are inoperative whenever the coil of the fan switch-off relay is energised. This is achieved by having the common contact (C2) of the relay connected to earth, when the coil is energised it removes the earth path from the compressor and effectively puts an earth path on the fan speed power circuit therefore preventing the fans from operating. When the relay coil is de-energised the earth path is removed and the compressor earth path is restored.

The coil of the fan switch-off relay has two earth paths; one when the oil pressure switch is closed (ie. no oil pressure) and also when the coil of the fan delay relay is energised with either the fan delay thermostat closed (below 44°C) or the lower quantity flap microswitch closed. This second earth path (via the contacts of the fan delay relay) provides the necessary signal to hold off the fans and compressor when the coolant is below 44°C and the mode is to 'screen' and the lower quantity flap is not fully open. It also prevents the fans from being inhibited when DEFROST has been selected. The live feed to energise the coil of the fan delay relay is switched by the 25% mode change microswitch in the upper servo. When the mode is to 'screen' the orange/purple cable from the upper servo is 'live' which feeds the fan delay relay coil via the diode block and yellow cable via toeboard socket D to W2. The earth path for the relay coil is through the ACU switch to the left-hand 'A' post earth (except when DEFROST has been selected).

In addition, the lower quantity flap microswitch initiates a fixed sequence of events when the fan delay thermostat opens. When the coolant tempe-





Fig. C20 1. Fan switch-off relay
2. Lower quantity relay
Right-hand drive cars




Fig. C21 1. Lower quantity relay
2. Fan switch-off relay
Left-hand drive cars

perature is below 44 °C, the fan delay thermostat not only inhibits the fans and compressor but also energises the coil of the lower quantity relay which keeps the lower quantity flap closed. As soon as the coolant exceeds 44 °C the thermostat opens which disconnects the earth from the lower quantity relay and allows the lower quantity flap to open, when fully open it opens the lower quantity flap microswitch thereby allowing the fans and compressor to operate. Therefore, the fans do not operate until the lower quantity flap is fully open.

In (3), to prevent the fans operating when the car is started with a 'hot' engine which could cause misting of the windscreen, a 13 second delay is initiated by connecting the fan speed module to the starter motor (brown-blue cable) which activates a 13 second delay circuit in the module each time the starter motor is used. This allows the compressor to freeze any condensed water vapour in the system so preventing any misting of the windscreen.

Note

The diode between the fan switch-off relay coil and oil pressure switch prevents the warning lamp from finding an earth path through the fan switch-off






Fig. C22 Fan delay thermostat

relay coil, fan and compressor relay coil and starter motor. If this diode fails short circuit, the oil pressure warning light would glow dimly with the ACU switched off.


Interlock circuit

Schematic wiring diagram


Fig. C22




Toeboard sockets



Right-hand valance earth



Location of main distribution loom plug (MDI)



- Components
- 1 ACU function switch
 - 2 Fuse number 3
 - 3 Ignition switch
 - 4 Battery
 - 5 ACU diode board
 - 6 Starter relay
 - 7 Starter motor
 - 8 Fan speed module
 - 9 Fan and compressor relay
 - 10 Fan and compressor fuse
 - 11 Servo isolation relay
 - 12 Upper servo microswitches
 - 13 Compressor clutch thermostat
 - 14 Compressor protection unit
 - 15 Compressor clutch
 - 16 Compressor protection sensor
 - 17 Lower quantity actuator
 - 18 Lower quantity flap microswitch
 - 19 Fan switch-off relay
 - 20 Fan delay relay
 - 21 Oil pressure switch
 - 22 Left-hand 'A' post earth
 - 23 Fan delay thermostat
 - 24 Right-hand valance earth
 - 25 Lower quantity relay
 - 26 Right-hand 'A' post earth
 - 27 Starter switch
 - 28 Servos

Inhibit circuit

Schematic wiring diagram

Fig. C23

3

Section C5

System test and fault diagnosis Contents

	Page
Introduction	C5 - 3
Connector and cable colour codes	C5 - 3
Theoretical wiring diagram	C5 - 5
Initial test	C5 - 7
Sensor chains	
Wiring diagram	C5 - 11
Temperature v resistance graphs	C5 - 13
Upper system fault-finding charts	C5 - 15
Lower system fault-finding charts	C5 - 19
Servo fault-finding charts	C5 - 23
Fan fault-finding charts	
Fans inoperative in all situations	C5 - 31
Fans inoperative in LOW, AUTO and HIGH	C5 - 33
Fan speed does not vary	C5 - 35
Flaps and actuators fault-finding charts	
Mode flap and actuator	C5 - 37
Lower quantity flap and actuator	C5 - 39
Recirculation flaps and actuator	C5 - 41
ACU switch wiring diagram and testing	C5 - 45
Refrigeration system	
Compressor thermal fuse fault diagnosis	C - 47
Voltage stabiliser fault diagnosis	C5 - 49
Upper servo test and calibration	C5 - 53
procedure	
Lower servo test and calibration	C5 - 57
procedure	
Test procedure for recirculation, lower quantity, mode change, fan inhibit and rear window demist circuits	C5 - 61

C5 ACU Ref

Section C5

A.C.U. test box

Description

The automatic air conditioning system test box (RH 8851) enables the air conditioning system to be tested whilst the components are fitted to the car. The function of the controls on the box are as follows:

1. AUTO/CAL switch.

When AUTO is selected and the ACU is in 'automatic' mode, the test box functions as a servo position indicator. When CAL is selected, the test box can be calibrated.

2. UPPER/LOWER switch.

Selects the appropriate circuit under test.

3. MAX control

With the AUTO/CAL switch set to CAL and the 0% 100% switch set to 100%, the meter can be adjusted to 100%.

4. CHECK VOLTS switch

Measures the following:

Position 1. Supply voltage to the servo modules (9.1 volts)

Position 2. Output voltage from lower servo position potentiometer.

Position 3. Output voltage from lower sensor chain.

Position 4. Output voltage from upper servo position potentiometer.

Position 5. Output voltage from upper sensor chain.

5. IND/VOLTS switch

Determines whether the meter is to be used as a voltmeter or a servo position indicator.

6. 0%/100% switch.

Enables the test box to be calibrated to the servo under test.

7. ZERO control

With the AUTO/CAL switch set to CAL and the 0%/100% switch set to 0%, the meter can be adjusted to 0%.

8. RUN/SET switch

In the RUN position, the switch enables a servo to be operated in the automatic mode or calibrated. In the SET position, the temperature selector dials can be calibrated to a specific servo position.

Using the test box as a voltmeter

1. Set AUTO/CAL switch to AUTO and the RUN/SET switch to RUN.

2. Set IND/VOLTS switch to VOLTS.

3. Select the appropriate switch position as follows:

Position 1. Supply voltage to the servo modules (9.1 volts)

Position 2. Output voltage from lower servo position potentiometer.




Fig. C33 Test box details

- 1 Volts scale
- 2 Servo position scale
- 3 RUN/SET switch
- 4 Input plug
- 5 ZERO control
- 6 0%/100% switch
- 7 IND/VOLT switch
- 8 CHECK VOLTS control
- 9 MAX control
- 10 UPPER/LOWER servo switch
- 11 AUTO/CAL switch

Position 3. Output voltage from lower sensor chain.
Position 4. Output voltage from upper servo position potentiometer.

Position 5. Output voltage from upper sensor chain.

C5 ACU Ref




Fig. C34 Test box in position

- 1 Servo trim cover 5 way socket
- 2 Servo assembly
- 3 Test box RH 8851

Calibrating the test box as a servo position indicator.

1. Connect the test box to the test socket.
2. Select the required servo on the UPPER/LOWER SERVO switch.
3. Set IND, CAL and RUN on the appropriate switches.
4. Disconnect the socket situated under the servo trim cover, start the car engine and select LOW on the ACU function switch.
5. Set the 0%/100% switch to 0% and wait for the servo to stop.
6. Adjust the ZERO control to set the meter to 0%.
7. Set the 0%/100% switch to 100% and wait for the servo to stop.
8. Adjust the MAX control to set the meter to 100%.
9. Repeat operations 5 to 8 until both readings are correct.

Important

A servo may appear to have travelled to the limit switch (operations 5 and 7) and the test box adjusted accordingly but, in fact, the servo has stalled. If a stall condition is suspected the supply voltage to the servo motor should be measured at the servo socket where a voltmeter probe can be inserted. The upper servo supply is at the pink/blue cable and the lower servo supply is at the pink/light green cable. If a stall condition exists the voltage between the servo supply and earth will be less than 8 volts, otherwise the voltage should be greater than 12 volts.

Servo position indicator with ACU operating automatically

1. Select the required servo on the UPPER/LOWER SERVO switch and calibrate the test box.
2. Set the AUTO/CAL switch to AUTO.
3. Set the RUN/SET switch to RUN.
4. Ensure that the servo trim cover socket is connected.

Servo position indicator with manual control of ACU.

To observe the operation of the actuators and water tap, set up the test box as follows:

1. Select the required servo on the UPPER/LOWER SERVO switch and calibrate the test box.
2. Set the AUTO/CAL switch to CAL.
3. Set the RUN/SET switch to SET.
4. The servo may now be set to any required position using the temperature selectors on the facia but to achieve the extremes of servo position the servo trim potentiometers will have to be used.

Calibrating the temperature selectors

Correct servo position is related to selector position, in-car temperature and outside air temperature, therefore, to calibrate the temperature selectors, the servo positions are adjusted with the temperature sensors substituted by known fixed resistances. To obtain the correct temperature settings, the upper servo must be set to 51% and the lower servo set to 48% with the temperature selectors set to mid-range. The temperature selector calibration procedure is as follows:

1. Select the appropriate servo and calibrate the test box.
2. Set the AUTO/CAL switch to CAL.
3. Set the RUN/SET switch to SET
4. Disconnect the servo trim cover socket.
5. Set both temperature selectors to their mid-position.
6. Adjust the servo trim potentiometer until the meter reads 51% for the upper servo and 48% for the lower servo. Approach the setting from 0%.

ACU QUICK CHECK

1. Remove servo trim cover. Do not disconnect 5 way socket.
2. Connect test box into the servo test socket.
3. On the test box:-
 Switch ind/volts switch to volts position
 run/set switch to run position
 auto/cal switch to auto position
 0% 100% switch to 100% position
4. On the car:-
 turn upper and lower temperature selector knobs to mid-position (i.e. 12 o'clock)
 turn ACU switch to low
5. Disconnect oil pressure switch. White, brown wire, switch is on front, left hand side of engine.
6. Switch on ignition. A number of actuators will now run, but should stop within a few seconds. The fans will blow at minimum speed.
7. On the test box:-

switch check volts switch to position:-

- | | | | | | |
|----|---------|---------|----|-----|----|
| 1. | Reading | 91 | ± | 5 | |
| 2. | Reading | between | 10 | and | 40 |
| 3. | " | " | " | " | " |
| 4. | " | " | " | " | " |
| 5. | " | " | " | " | " |

Return switch to position 1.

If readings are incorrect see below.

If readings 1, 2, or 4 are incorrect there is a fault in the servo, stabiliser or boom and this must be rectified before proceeding. Refer to fault diagnosis. If readings 3 or 5 are not as specified there is a fault in the temperature sensor networks. However, one can proceed with the setting instructions and the fault can be rectified after instruction 25.

8. Switch off ignition.
9. Disconnect 5 way servo trim cover socket.

- d. Switch 0%/100% switch to 100%, wait or servo to stop. Throughout items 15A to 15E the ACU actuators will run randomly and the fans will be switched off and on, this is normal.
- e. Adjust max control to make meter read 100.
- f. Repeat items 15C to 15E until both readings are correct. Meter is now calibrated as a servo position indicator for the upper servo.

Switch run/set switch to set. Wait for servo to stop. The reading should be $51\% \pm 3\%$.

Disconnect fan delay thermostat (yellow/brown wire, right-hand front of engine), lower quantity flap will open, when fully open fans should start and airflow will be to screen.

Turn temperature selector fully left, the reading should be between 0% and 20% preferably 0%. Assuming a reading of 0%, turn selector slowly to the right. At 5% the recirculatory actuator should run, at $10\% \pm 3\%$ the lower quantity flap. Fully right the reading should be between 80% and 100%. If a reading of 0% is not obtained, this check can be done using the trim screw. Remember to reset at 51% with selector in mid-position.

21. Adjust upper servo trim pot clockwise to move servo until meter reading is 51 approaching this from 0 not 100. If servo overshoots approach reading from 100 once more.

This has set up the upper servo to calibrate the upper temperature selector knob. Thus the reading of 51 must be set up very carefully.

22. Switch air conditioner to 'off'

Check:-

1. Recirc actuators have opened.
2. Fans have stopped.

23. Switch air conditioner switch to 'low'.

Check:-

1. Recirc actuators have closed.
2. Fans have re-started.

24. Switch off ignition

- a. Re-connect 5 way trip cover socket
- b. Switch test box 'off'
- c. Remove test box

10. On the test box, switch:-

Auto/cal switch to 'Cal'
Ind/volts switch to 'Ind'

Adjust 'Max' control fully anti-clockwise.

11. Switch on ignition. Both servos will run to full hot, number of actuators will now run but will stop within few seconds. The fans will not be running.

IF THE SERVO FAILS TO MOVE THIS MUST BE REPAIRED BEFORE PROCEEDING

12. On the test box, switch:-

- a. Upper/lower switch to 'lower'
0%/100% switch to 0% lower servo will run to full cold and close the water tap
- b. Adjust 'zero' control to make read 0
- c. Switch 0%/100% switch to 100%. Wait for servo to stop. Lower servo will run to full hot, opening the water tap as it moves.
- d. Adjust 'max' control to make meter read 100.
- e. Repeat 12A to 12D until both readings are correct. Finish this procedure with the 0%/100% switch in the 0% position.

Item 12 has now calibrated the meter as a servo position indicator, 0 being full cold and 100 full hot. The meter has a linear response, i.e. 50 is mid-servo-position.

13. On the test box:-

Switch run/set switch to 'set'. Servo may now run and then stop, this is irrelevant. Meter reading should be $43\% \pm 3\%$, if not adjust approaching 43 from zero.

14. Turn temperature selector fully left, reading should be between 0% and 5% turn fully right, reading should be 80% to 100%.

15. On the test box:-

- a. Switch run/set switch to 'run'. Lower servo will run to full cold.
- b. Switch upper/lower switch to 'upper'. Lower servo will run to full hot, upper servo will run to full cold. Fans will start to run at minimum speed, all the ACU actuators will run and then stop. Positions of these will be checked later.
- c. With 0%/100% switch in the 0% position, adjust zero control until meter reads 0.

Section C5

System test and
fault diagnosis

Introduction

This section describes the complete system test procedure and includes fault-finding charts that can be used to quickly diagnose a fault when time is not available to complete the test procedure. However, when time is available, the test procedure should be carried out.

To use the fault-finding charts, first complete the road test described in this section noting each malfunction. A guide, indicating the appropriate chart to use, is given at the completion of the road test.

Connector and cable colour codes



Connector code

The wiring diagrams are basically theoretical circuits showing all plug and socket connectors, which can be identified using the following code. The pin numbers referred to are viewed with the plug inserted and do not necessarily correspond with the numbers moulded on the plug and socket.

Code	Location
ACU	ACU switch sockets
B	Body socket
C	Console
D	Door socket
FA	Fuseboard 'A'
FB	Fuseboard 'B'
V	Valance
MD	Main distribution
TA	Toeboard socket 'A'
TM	Toeboard socket M
SCS	Sensor connector socket

Cable colour code


B	Black	LG	Light green
N	Brown	U	Blue
R	Red	S	Slate
O	Orange	P	Purple
Y	Yellow	W	White
G	Green	K	Pink



Section C5

**System test and
fault diagnosis**

Theoretical wiring diagram
Automatic air conditioning unit
Fig. C35



System test and fault diagnosis

Initial tests

Introduction

These initial tests describe the sequence of events that should occur when the ACU is switched on, one test applies to a car with a 'cold' engine, the other test applies to a car with a 'hot' engine i.e. when the coolant is above 44 °C.

'Cold' engine

1. Turn ACU switch to AUTO and both temperature selectors to maximum temperature position. Start engine.

The fans should not operate

2. The lower quantity flap should be closed

3. The recirculation flaps should be in the 'Fresh Air' position.

4. As the engine coolant warms up, the lower quantity flap should open

5. The fans should start operating ONLY when the lower quantity flap is fully open

6. Warm air will flow from the windscreen outlets

7. Warm air will also flow from the front and rear footwells.

8. Turn the ACU switch to DEFROST
Verify that the lower quantity flap has closed.

9. The fans should run at a fixed fast speed

10. Air should only flow from the screen outlets

The right-hand column indicates which fault diagnosis chart to use or which part of the system is probably faulty. However, the test should be completed fully before attempting any rectification to enable a complete picture of the malfunction to be given.

Interlock or Inhibit circuits faulty.

Lower quantity flap fault diagnosis.

Recirculation flap fault diagnosis ACU switch faulty.

Lower quantity flap fault diagnosis.

Lower quantity flap fault diagnosis.

No airflow - Fans inoperative fault diagnosis.

Airflow from facia - Mode flap fault diagnosis.

Incorrect air temperature - Water tap incorrect.

Upper servo fault diagnosis. Sensor chain fault diagnosis.

Lower quantity flap fault diagnosis

ACU switch fault

Lower quantity flap fault diagnosis

Fan speed module

Mode flap fault diagnosis, ACU switch faulty.

Upper servo fault diagnosis

C 5 - 8

11. Set the Mode Change switch to FACIA

The airflow should now flow from the facia outlets

Mode change switch faulty. Mode change relay faulty

12. Set the Mode Change switch to AUTO

The airflow should now be from the windscreen outlets

Mode change switch or mode change relay faulty

13. Set the Mode Change switch to FACIA

Airflow should be from facia outlets

Mode change switch or mode change relay faulty

14. Switch off the Ignition and immediately restart the engine

The fans should not operate for approximately 13 seconds

Inhibit circuit faulty

15. Airflow should now only be from the windscreen outlets

Mode change switch or Mode change relay faulty

16. Let the 'In-car' temperature rise to an uncomfortable level to enable the mode, lower quantity and recirculation flaps to be tested.

17. Set the ACU switch to AUTO and both temperature selectors to the minimum temperature position. The airflow should only be from the facia outlets

Mode flap fault diagnosis

18. The lower quantity flap should be closed

Lower quantity flap fault diagnosis

19. The recirculation flaps should be in the 'Recirculation' position

Note. This can only be achieved with a combination of high 'In-car' temperature and an outside temperature above 5 °C

Recirculation flap fault diagnosis

20. Slowly rotate the upper temperature selector away from the minimum temperature position

The recirculation flaps should move to the 'Fresh air' position

Recirculation flaps fault diagnosis

21. The lower quantity flap should open

Lower quantity flap fault diagnosis

22. Stop rotating the temperature selector

Airflow should only be from the facia outlets and front and rear footwells

Mode flap fault diagnosis

23. Switch off ignition & restart engine

The fans should start immediately

Fans inoperative fault diagnosis

24. Continue rotating the upper temperature selector away from the minimum temperature position until the Mode flap operates
Airflow should be from the windscreen outlets and the front & rear footwells

Mode flap fault diagnosis

25. Set both temperature selectors to the 'preferred' temperature position. Set the ACU switch to HIGH
The fan speed should increase

Fan speed does not vary fault diagnosis

26. Set the ACU switch to LOW
The fan speed should decrease

Fan speed does not vary fault diagnosis

27. Set the ACU switch to AUTO & drive the car on the road. Ensure that the system stabilises, giving a comfortable in-car temperature. Stabilisation is achieved when the fan speed decreases & becomes constant although this may not occur if the outside temperature is extremely high or low.

28. When the road test is completed and with the engine still running, raise the car bonnet and inspect the condition of the refrigerant through the sight glass of the receiver/drier.
There should not be any bubbles or foaming

Refrigeration system faulty

'Hot' engine

1. Disconnect the yellow/brown cable and the black cable from the 44 °C fan delay thermostat and connect them together. Set the ACU switch to AUTO and both temperature selectors to the maximum temperature position. Start the engine
The fans should not operate

Interlock or Inhibit circuits faulty

2. The lower quantity flap should be closed

Lower quantity flap fault diagnosis

3. The recirculation flaps should be in the 'Fresh air' position

Recirculation flap fault diagnosis

4. Switch off the engine & reconnect the yellow/brown and black cables to the fan delay thermostat. Start the engine.
The lower quantity flap should be open

Lower quantity flap fault diagnosis

5. The fans should not operate for approximately 13 seconds

Inhibit circuit


For the remainder of this test, refer to paragraphs 6 to 28 of 'Initial test - cold engine'.

Section C5

System test and
fault diagnosis

Upper and lower sensor chains

Fig. C36



Components


- 1 Upper servo module
 - 2 Upper servo
 - 3 Lower servo
 - 4 Lower servo module
 - 5 Upper temperature selector
 - 6 Lower temperature selector
 - 7 Sensor connection socket
 - 8 Solar sensor
 - 9 Cantrail sensor
 - 10 Knee roll sensor
 - 11 Outside air temperature sensor (upper system)
 - 12 Outside air temperature sensor (lower system)
 - 13 ACU switch
 - 14 RH 'A' post earth
- LS Lower servo
US Upper servo
RB9 Right-hand body socket 9 way
RTE Right-hand toeboard socket E

Section C5

**System test and
fault diagnosis**


Sensor chain resistance/temperature
graphs

Fig. C37




Graph 1

S 965




Graph 2

S 967




Graph 3

S 966




Graph 4

S 983



Graph 5

S 968



Graph 6

S 964


Section C5

**System test and
fault diagnosis**

Upper sensor chain fault diagnosis

Fig. C38

If a cable fault is indicated when using this chart,
refer to next page to isolate the fault.



Section C5

System test and fault diagnosis

Upper sensor chain cable faults

Fig. C39








This chart enables the user to isolate a cable fault in the sensor chain by separately testing each cable for open circuit (broken cable) or short circuit (earth fault).

When a cable fault is suspected, disconnect the first cable as shown at the top of the chart, test it with the resistance meter and if it is satisfactory, reconnect it and test the next cable in the circuit. If a faulty cable is found, rectify the fault and measure the total sensor chain resistance to ensure that another fault does not exist.

If the fault is a short circuit, the simplest remedy is to sever the cable at each end by cutting it or disconnecting it and insulating the ends with tape, then insert a new length of cable.

Fault location

Resistance meter connection



Connect meter between pin 3 of sensor chain socket (yellow/white cable) and 'A' post earth.

Connect meter between pin 3 of sensor chain socket and pin 2 of right-hand body socket (yellow/white cable).

Connect meter between pin 3 of right-hand body socket and yellow/white cable at cantrail sensor.


Connect meter between yellow/white cable at cantrail sensor and a good earth.

Connect meter between yellow/blue connection at solar sensor and pin 3 at right-hand body socket.

Connect meter between pin 3 at right-hand body socket and 'A' post earth.

Connect meter between yellow/blue cable at cantrail sensor and yellow/blue cable at outside temperature sensor.

Connect meter between yellow/blue cable at outside temperature sensor and boot earth.



For cable faults on the range cable between outside temperature sensor and CU switch, refer to chart for lower


Section C5

System test and fault diagnosis

Lower sensor chain fault diagnosis

Fig. C40

If a cable fault is indicated when using this chart,
refer to next page to isolate the fault.










Section C5

**System test and
fault diagnosis****Lower sensor chain cable faults****Fig. C41**


This chart enables the user to isolate a cable fault in the sensor chain by separately testing each cable for open circuit (broken cable), or short circuit (earth fault).

When a cable fault is suspected, disconnect the first cable as shown at the top of the chart, test it with the resistance meter and if it is satisfactory, reconnect it and test the next cable in the circuit. If a faulty cable is found, rectify the fault and measure the total sensor chain resistance to ensure that another fault does not exist.


If the fault is a short circuit, the simplest remedy is to sever the cable at each end by cutting it or disconnecting it and insulating the ends with tape, then insert a new length of cable.



Resistance meter connection



Fault location




∞ = Meter reading over 100 000 Ω

Section C5

**System test and
fault diagnosis**

Servo fault diagnosis
Fig. C42

Sheet 1 of 4




Section C5

**System test and
fault diagnosis**

Servo fault diagnosis
Fig. C42 continued

Sheet 2 of 4




Section C5

**System test and
fault diagnosis**

Servo fault diagnosis
Fig. C42 continued

Sheet 3 of 4




Section C 5

**System test and
fault diagnosis**

Servo fault diagnosis
Fig. C42 continued

Sheet 4 of 4




Section C5


**System test and
fault diagnosis**

Fans inoperative in all situations


Fig. C43




Fan and compressor relay



Fan switch-off relay right-hand drive cars. For left-hand drive cars, see Section C4.



Toeboard socket (engine side)




Section C5

**System test and
fault diagnosis**

Fans inoperative in LOW AUTO and HIGH

Fig. C44




Section C5

**System test and
fault diagnosis**

Fan speed does not vary

Fig. C45



Section C5

**System test and
fault diagnosis**

Recirculation flaps inoperative

Fig. C47



Section C5

**System test and
fault diagnosis**


Lower quantity flap inoperative

Sheet 1 of 2


Fig. C48




Lower quantity flap actuator right-hand drive cars.




Lower quantity flap actuator left-hand drive cars.




Location of sensor chain socket.




Sensor chain socket.



1. Hazard switch socket
2. A.C.U. sockets



Fan delay thermostat.



Lower quantity relay.



Section C5

**System test and
fault diagnosis**


Lower quantity flap inoperative

Sheet 2 of 2


Fig. C48 continued



Diode board, left-hand drive cars, viewed with top roll removed.



Diode board, right-hand drive cars.




1. Hazard switch socket
2. A.C.U. sockets

Section C5

System test and
fault diagnosis

ACU switch wiring diagram and testing

Fig. C49



Resistance meter connection:

	Blue/green & blue/red	Orange/black & red/brown	Black & orange	Red/brown & brown/pink	Yellow/black & blue/brown	Orange/yellow & blue/brown
OFF	Short circuit	Open circuit	Short circuit	Open circuit	Open circuit	Open circuit
LOW	Short circuit	Open circuit	Short circuit	Short circuit	36 K	Open circuit
AUTO	Short circuit	Open circuit	Short circuit	Short circuit	Open circuit	6.8 K
HIGH	Short circuit	Open circuit	Short circuit	Short circuit	Open circuit	Open circuit
DEF	Open circuit	Short circuit	Open circuit	Short circuit	Open circuit	Open circuit

Section C5

System test and fault diagnosis


Compressor thermal fuse fault diagnosis

Fig. C50

This chart should be used to locate the cause of a thermal fuse 'blowing' in the compressor protection unit.

The air temperature surrounding the car must be above 24 °C before this diagnosis can be carried out.

C5 - 48




Section C5

**System test and
fault diagnosis**

Voltage stabiliser

Sheet 1 of 2

Fig. C51



Section C5

**System test and
fault diagnosis**




Voltage stabiliser

Sheet 2 of 2

Fig. C51 continued

Have you checked the battery voltage?

From page 1



Section C5

**System test and
fault diagnosis**


Upper servo test and calibration procedure

Sheet 1 of 2

Fig. C52

Sheet 1 of 2

Ensure that the battery is fully charged



Section C5


**System test and
fault diagnosis**

Upper servo test and calibration procedure

Sheet 2 of 2

Fig. C52 continued


From sheet 1




These are landmarks. They show which part of the system has been proved correct.

The upper temperature blend flap is now correctly set.

The upper servo and upper servo module are now proven to operate correctly from the test box. If a fault still exists, refer to the UPPER SENSOR CHAIN FAULT DIAGNOSIS



Servo assembly



Section C5

**System test and
fault diagnosis**


Lower servo test and calibration procedure

Sheet 1 of 2




Fig. C53

Sheet 1 of 2

Ensure that the battery is fully charged



ACU switch settings



Section C5


**System test and
fault diagnosis**

Lower servo test and calibration procedure

Sheet 2 of 2

Fig. C53 continued


From sheet 1




These are landmarks. They show which part of the system has been proved correct.

The lower temperature blend flap is now correctly set

The lower servo and lower servo module are now proven to operate correctly from the test box. If a fault still exists, refer to the LOWER SENSOR CHAIN FAULT DIAGNOSIS



Servo assembly



Section C5

**System test and
fault diagnosis**

Test procedure for recirculation,
lower quantity, mode change,
fan inhibit and rear window demist circuits.

Sheet 1 of 7

Fig. C54


Start

Disconnect the white/brown cable from the oil pressure switch.
Disconnect the sensor chain socket.
Connect the test box into the servo test socket.


On the test box set the following:
IND/VOLTS to IND. RUN/SET to RUN.
AUTO/CAL to CAL. UPPER/LOWER SERVO to UPPER.
CHECK VOLTS to Position 1.

On the car, set the upper temperature switch to the mid-position and the ACU switch to LOW. Switch on the ignition.

On the test box, set the 0%/100% switch to 0% and adjust ZERO control until meter indicates 0%. Set the 0%/100% switch to 100% and adjust MAX control until meter indicates 100%. Repeat both operations until both readings are correct.





Oil pressure switch




Test box connection

On the test box, set the RUN/SET switch to SET and the 0%/100% switch to 0%. Turn the upper servo trim potentiometer fully anti-clockwise and wait for the servo to stop. If the meter reading is not 0%, turn the upper temperature selector towards the minimum temperature position until 0% is obtained.



ACU switch settings



Servo assembly



Section C5

**System test and
fault diagnosis**

Test procedure for recirculation,
lower quantity, mode change,
fan inhibit and rear window demist circuits.

Sheet 2 of 7

Fig. C54 continued



Servo assembly

Section C5



**System test and
fault diagnosis**

Test procedure for recirculation,
lower quantity, mode change,
fan inhibit and rear window demist circuits.

Sheet 3 of 7

Fig. C54 continued

From sheet 1
Lower quantity actuator



Servo assembly


Section C5

**System test and
fault diagnosis**

Test procedure for recirculation,
lower quantity, mode change,
fan inhibit and rear window demist circuits.

Sheet 4 of 7

Fig. C54 continued



Window demist relay

These are landmarks. They show which part of the system has been proved correct.


Section C5**System test and
fault diagnosis**

Test procedure for recirculation,
lower quantity, mode change,
fan inhibit and rear window demist circuits.


Sheet 5 of 7

Fig. C54 continued


From sheet 4



Right-hand body sockets



Rear window demist



Rear window demist socket & Right-hand boot earth

These are landmarks. They show which part of the system has been proved correct.

Section C5

**System test and
fault diagnosis**



Test procedure for recirculation,
lower quantity, mode change,
fan inhibit and rear window demist circuits.

Sheet 6 of 7



Fig. C54 continued

Sheet 6 of 7


From sheet 1 Fans inhibit circuit




Fan delay thermostat




1. Fan and compressor relay
2. Fan delay relay
3. Servo isolation relay



Location of fan switch-off relay and lower quantity relay right-hand drive cars



1. Fan switch-off relay
2. Lower quantity relay




Location of fan switch-off relay and lower quantity relay left-hand drive cars

Section C5

**System test and
fault diagnosis**

Test procedure for recirculation,
lower quantity, mode change,
fan inhibit and rear window demist circuits.
Sheet 7 of 7
Fig. C54 continued

These are landmarks. They show which part of the system has been proved correct.



Refrigeration system

Contents	Pages			
	Silver Spirit Mulsanne	Silver Spur	Mulsanne Turbo	Corniche
Basic operation	C6-1	C6-1	C6-1	C6-1
Servicing the refrigeration system	C6-2	C6-2	C6-2	C6-2
Fault diagnosis	C6-4	C6-4	C6-4	C6-4
Rear compartment air conditioning system	—	C6-11	—	—

Refrigeration system

Basic operation (see figs. C6-1 and C6-4)

The refrigerant (Refrigerant 12) is circulated by a compressor driven from the engine crankshaft. An electro-magnetic clutch, incorporated in the compressor, is energised in the engaged position when the engine is running, except when the ambient temperature is below 0°C.

The refrigerant is pumped from the compressor as a high pressure vapour to the top of the condenser matrix, where it condenses from a vapour into a high pressure liquid at the bottom of the matrix.

From the condenser matrix the liquid is passed to the EE model valves-in-receiver (EEVIR) unit where any moisture present is absorbed by a dessicant bag. Within the EEVIR unit, the amount of liquid passed to the evaporator matrix is controlled by a pressure and temperature sensitive valve (TX valve).

The evaporator matrix absorbs heat from the air passing through it, evaporating the refrigerant and thereby cooling the air.

From the evaporator matrix the refrigerant, (now a low pressure vapour) is passed to the pressure operated absolute suction throttling valve (POAST valve) situated adjacent to the TX valve in the EEVIR unit. The POAST valve controls the flow of refrigerant from the evaporator matrix to maintain a constant pressure within the evaporator.

From the POAST valve the refrigerant is returned to the compressor as a low pressure vapour.

Special precautions

The refrigerant used in the air conditioning system is dichlorodifluoromethane (Refrigerant 12). It is supplied to the service network in disposable containers or metal drums.

When correctly handled the refrigerant is perfectly safe, however incorrect handling could result in injury or accident.

The following precautions must always be observed.

1. Do not smoke in the vicinity of refrigerant or a refrigeration system.
2. Always wear safety glasses when working on a refrigeration system.
3. Store refrigerant containers upright and away from direct sunlight.
4. When transporting refrigerant ensure that the containers are secured, remain upright and away from direct sunlight.
5. Ensure that caps are fitted to drums when not in use.
6. Refrigerant containers must not be overfilled, increased pressure could cause an explosion.
7. To heat the drum when charging a system, immerse in warm water with a maximum temperature of 51°C.




Fig. C6-1 Refrigerant flow

- | | |
|---------------------|----------------------|
| 1. Compressor | 3. EEVIR unit |
| 2. Condenser matrix | 4. Evaporator matrix |

- ⇒⇒⇒ High pressure vapour
- High pressure liquid
- ⇐⇐⇐ Low pressure vapour
- ◆◆◆ Low pressure liquid

Never place the drum on a hot surface or attempt to heat the drum by means of a blowlamp, etc.

8. Do not discharge refrigerant in confined spaces or near to exposed flames. Contact with exposed flames can produce a toxic gas.

Always keep refrigerant clear of engine air intakes.

9. Excessive heat applied to any part of the refrigeration system will create high pressures within the system. Therefore welding, soldering or brazing should not be carried out on the system, or to any adjacent part of the car.

Accident damage

The following guidelines should be observed when carrying out repairs.

1. If the car is to be driven before repair work is carried out ensure that the compressor clutch is disengaged. This can be achieved by disconnecting the blue/yellow cable from the compressor ambient switch (see fig. C6-4).
2. Inspect all refrigeration components and lines to ascertain the extent of the damage.

3. If the condenser has been damaged it must be renewed. Welding, soldering or brazing must not be attempted.
4. If damage has occurred to the system or if it has been 'open' for more than a day, fit a new dessicant bag.



Fig. C6-2 Refrigerant handling – safety precautions




Fig. C6-3 Manifold gauge set

- 1 Low side hand valve
- 2 Connection to EEVIR unit
- 3 Charging or evacuating connection
- 4 Connection to compressor
- 5 High side hand valve

5. Inspect the compressor and clutch pulley for cracks. If cracks are apparent replace components as necessary.
6. If the clutch plate is discoloured it must be replaced. Discolouration indicates that the clutch plate has burnt out.
7. If the compressor does not show signs of damage it may be used again.

Chemical stability

The following general rules should be observed to ensure that the chemical stability of the refrigerant is maintained.

1. Before releasing a refrigerant connection, wipe away all dirt or oil from the connection to prevent foreign matter entering the system.
2. All tools and containers should be kept clean and dry to prevent moisture from entering the system.
3. Ensure that the system is not left 'open' any longer than necessary.
4. If the system has been opened and then sealed again, it must be correctly evacuated.

Servicing the refrigeration system

To discharge

The refrigerant must be discharged from the system before opening a connection. Ensure that the special precautions described on page C6-1 are always observed.

1. Remove the caps from the compressor discharge valve and from the service connection of the EEVIR unit. Attach the manifold gauge set (with depressors fitted and valves closed). Attach a pipe to the centre connection of the gauge set and direct this pipe into a clean container to collect any refrigerant oil discharged with the refrigerant.
2. Do not release the refrigerant too quickly as this will result in more oil than is necessary being drawn from the system.
3. Fractionally open both hand valves. Open further as the system discharges. The operation requires at least 15 minutes to ensure complete discharge.
4. When all the refrigerant appears to have discharged, slacken the adapter to close the valve and allow approximately two minutes for any build up of pressure to develop. Then, repeat the discharge procedure until all refrigerant has been discharged.
5. Measure any oil which has discharged into the container and add a corresponding amount of new refrigerant oil to the system.

To evacuate

1. Ensure that the system is fully discharged.
2. Connect the centre pipe of the manifold gauge set to the vacuum pump. The vacuum pump must be capable of producing a minimum vacuum of 250 microns (0.250 torr, 0.250 mm Hg).
3. Open both valves on the manifold gauge set and switch on the vacuum pump.
4. Carry out evacuation until a minimum vacuum of 300 microns (0.300 torr, 0.300 mm Hg) is achieved.
5. Switch off the vacuum pump. If the vacuum level decreases steadily over a period of approximately three




Fig. C6-4 Refrigeration system component lay-out

- 1 Compressor thermal fuse
- 2 Compressor clutch
- 3 Compressor clutch coil connections
- 4 Compressor
- 5 Compressor discharge valve
- 6 Compressor ambient thermostat
- 7 Evaporator matrix

- 8 Servo assembly
- 9 EEVIR service connection
- 10 EEVIR unit
- 11 EEVIR sight glass
- 12 Coolant tap
- 13 Condenser matrix

minutes there is a leak in the system which must be rectified.

6. A slow leak in the level of vacuum indicates that there is moisture present in the system. Carry out evacuation for a further 45 minutes to eliminate the possibility of residual liquid refrigerant in the compressor oil vapourising and causing the pressure to rise.

7. The final vacuum reading obtained should be held for thirty minutes to ensure that there are no leaks in the system.

To sweep and charge

1. Evacuate the system.
2. Attach a cylinder of Refrigerant 12 to the appropriate connection on the vacuum pump apparatus.
3. Suspend the cylinder on a spring balance and record the weight.

Note

If a charging station or other type of refrigeration system servicing equipment is to be used, follow the manufacturers' instructions.

4. Open the tap on the vacuum pump apparatus to allow the refrigerant to flow into the system.
5. Ensure that the parking brake is applied, the gear range selector lever is in the Park position and that the gearchange isolator is removed.
6. Start the engine and run at between 1000 rev/min and 1250 rev/min.
7. Move both temperature selectors to the full cold position. Open the rectangular facia outlet and turn the air conditioning unit (ACU) function switch to HIGH.
8. Allow between 0,45 kg and 0,57 kg (1 lb and 1,250 lb) of refrigerant to flow into the system. Close the tap on the vacuum pump apparatus and switch off the engine.

TSD 4400

9. Test for leaks in the system using an electrical leak detector.

If the system is free of leaks continue the charging operation and increase the weight of refrigerant in the system to between 1,20 kg and 1,30 kg (2,650 lb and 2,850 lb).

10. If a leak is detected it must be rectified and the evacuation and charging operations repeated.

Note

The presence of bubbles or foam passing through the EEVIR sight glass is not a reliable indication of refrigerant deficiency if the ambient temperature is below 24°C.

11. Close the tap on the vacuum apparatus and release the service connection on the EEVIR unit. Fit the valve cap.

Oil level

The refrigeration pump is originally filled with 310 ml. (10.85 fl oz., 10.3 US oz) of Frigidaire 525 viscosity refrigeration oil and servicing is not normally required. However during normal system operation a small amount of oil combines with the refrigerant and circulates around the system.

If any oil escapes due to leakage, discharge of the refrigerant or replacement of a component, it must be replaced. It is important that the amount of oil in the system is always correct. Insufficient oil in the system will result in inadequate lubrication of the compressor. Too much oil in the system will reduce the cooling capacity of the system.

The procedure for correcting the oil level in the system is as follows.

1. Ensure that the parking brake is firmly applied and that the gear range selector lever is in the PARK position. Remove the gearchange isolator.

2. Run the engine at between 1000 rev/min and 1500 rev/min for ten minutes with the ACU function switch set to AUTO. This will allow the oil to be distributed throughout the system.

3. Stop the engine, discharge the refrigerant preserving any oil discharged with the refrigerant. Remove the compressor.

4. Position the compressor horizontally with the drain plug pointing downwards.

5. Remove the drain plug and allow the oil to drain into a clean measuring container; measure and discard the oil.

6. If the oil drained from the compressor is less than 125 ml (4.37 fl oz, 4.0 US oz) top-up the compressor with an equivalent amount of new refrigerant oil.

7. If the oil drained from the compressor is less than 125 ml (4.37 fl oz, 4.0 US oz) and a major oil loss has occurred, fill the compressor with 185 ml (6.48 fl oz, 6.0 US oz) of new refrigerant oil.

8. If the compressor has been overhauled increase the quantities given in the two previous operations by 30 ml (1.05 fl oz, 1.0 US oz).

9. If a new compressor is to be fitted the oil contained in it should be drained and measured. Then, the quantity adjusted to equal that drained from the original compressor. This amount should then be poured into the new compressor plus any oil lost through discharging of the refrigerant.

Replacing components

Whenever a refrigeration system component is replaced, measured quantities of approved refrigerant oil must be added to ensure that the total amount of oil in the system is maintained.

Oil should be added in the following quantities together with any oil lost through discharging the system.

Evaporator	90 ml	(3.15 fl oz, 3.0 US oz)
Condenser	30 ml	(1.05 fl oz, 1.0 US oz)
EEVIR unit	30 ml	(1.05 fl oz, 1.0 US oz)

Fault diagnosis

EE model valves-in-receiver (EEVIR) unit (see fig. C6-6)
At a temperature of 24°C and above the condition of the refrigerant can be visually inspected in the sight glass of the EEVIR unit.

After approximately five minutes of compressor operation a shortage of liquid refrigerant is indicated by the appearance of slow moving bubbles or by a broken column of refrigerant under the glass. Continuous bubbles may appear in a fully charged system on a cool day, however this is a normal condition. If the sight glass is generally clear and the system is functioning normally occasional bubbles do not indicate a shortage of refrigerant.

If the sight glass consistently shows foaming or a broken column of liquid, partially block the air flowing through the condenser matrix using a sheet of cardboard.

If this action clears the sight glass and the performance of the system is satisfactory, the refrigerant charge is considered adequate.

The sight glass also enables the colour of the TX valve in the casting to be observed. The valve must be the same gold allodine colour as the ring around the sight glass.



Fig. C6-5 Approved refrigerant oil

Expansion (TX) valve

Expansion valve failures will normally be indicated by low suction pressure, low discharge pressure and insufficient evaporator cooling.

Pressure operated absolute suction throttling (POAST) valve

A fault occurring in the POAST valve may cause evaporator pressure (and therefore air temperature) to be either too high or too low. No adjustment of the valve is possible, therefore if the valve is diagnosed as faulty it must be renewed.

Operating the car at higher altitudes will affect the performance of the POAST valve. To evaluate the performance refer to the following altitude corrected table.

Altitude of car		Gauge pressure	
metres	feet	Bar	lbf/in ²
0 (sea level)	0 (sea level)	1,96	28.50
300	1000	2,00	29.00
600	2000	2,03	29.50
900	3000	2,07	30.00
1200	4000	2,10	30.50
1500	5000	2,14	31.00
1800	6000	2,16	31.40
2100	7000	2,19	31.80
2400	8000	2,23	32.30
2700	9000	2,25	32.70
3000	10000	2,29	33.20

Condenser (see fig. C6-4)

A condenser fault can appear in two ways; it can either leak or become restricted. A restriction will result in excessive compressor discharge pressure. Ice or frost will form immediately after the restriction as the refrigerant expands after passing the restriction. Restriction of the airflow through the condenser or radiator will result in high discharge pressures.

During normal condenser operation the outlet pipe will be slightly cooler than the inlet pipe.

Condenser leakage will result in insufficient system cooling. If the condenser is leaking it must be renewed. Welding, soldering or brazing must not be attempted.

Compressor (see fig. C6-4)

Compressor malfunctions can be caused by electrical failure, low discharge pressure, noise or seizure.

Electrical failure

Using the wiring diagram for the refrigerant charge — protection system ensure that current is being supplied to the compressor clutch terminals before removing the compressor for service.

Low discharge pressure

Low compressor discharge pressure may be caused by a fault within the compressor. However, it is recommended that the refrigeration system is checked to ensure that the refrigerant charge is adequate and that there are no leaks or restrictions in the system before removing the compressor for service.




Fig. C6-6 EE model valves-in-receiver (EEVIR) unit

- 1 Inlet connector shell to housing 'O' ring
- 2 Expansion valve 'O' ring
- 3 Expansion valve capsule
- 4 Expansion valve lower 'O' ring
- 5 Expansion valve inlet
- 6 Liquid pick-up tube 'O' ring
- 7 Liquid pick-up tube
- 8 Pick-up tube filter
- 9 Receiver shell
- 10 Dessicant (drier) bag
- 11 Valve housing to receiver 'O' rings
- 12 POAST valve capsule
- 13 Valve capsule retainer screw and washer
- 14 POAST valve 'O' ring
- 15 Inlet connector shell assembly
- 16 Evaporator gauge connector (low pressure)

Noise or seizure

Resonant compressor noise can be ignored but an irregular noise or rattle may indicate damaged components or excessive wear. In these cases the compressor should be removed and repaired.

If the car has been stored for a long period or the air conditioning system not used, the oil drains away from the compressor pistons and axial plate. The resulting increased friction causes belt slip and noise. To overcome this condition (ensuring that there are no obvious signs of overheating or mechanical damage) adopt the following procedure.

1. With the engine switched off, disconnect the electrical connections at the compressor clutch.
2. Manually or using a wrench, rotate the compressor hub two or three turns anti-clockwise (opposite to its normal rotation). If the compressor hub will not turn remove and repair the compressor.
3. Reverse the procedure described in Operation 2.
4. Check the compressor drive belt tension as described in Chapter E.
5. Reconnect the electrical connections at the clutch.
6. Start the engine and run at 2000 rpm for at least one minute with the compressor operating. If the compressor now operates normally no further action is required.
7. If the noise level is still too high remove and repair the compressor.

Evaporator (see fig. C6-4)

An inadequate supply of cool air may indicate an evaporator fault. This will be caused by either a partially blocked core due to dirt, a cracked case or leakage from a seal. Therefore, if a fault exists rectify or replace the component as necessary.

Low refrigerant charge — Protection system







The low refrigerant charge protection system contains a superheat shut-off switch located in the rear of the compressor. It is connected in series to the compressor thermal fuse. The fuse is a temperature sensitive fusible link between the ACU ambient switch and the clutch coil connection.

During normal ACU operation current flows through the ambient switch and thermal fuse to the clutch coil, thereby actuating the compressor clutch. Partial or total loss of refrigerant causes the superheat switch to sense low system pressure and high suction gas temperature, thereby closing the switch contacts and melting the thermal fuse. This action prevents damage being caused to the compressor due to a low refrigerant charge.

The cause of lost refrigerant must be established and rectified. The system must then be evacuated and recharged before the thermal fuse is replaced.









Low refrigerant charge - Protection system

Wiring diagram and component location



Low refrigerant charge - Protection system

Wiring diagram and component location



Rear compartment air conditioning system



Silver Spur cars with a Centre Division

Component location, refrigerant flow, air flow, and wiring diagrams

Rear compartment air conditioning system

Silver Spur cars with a Centre Division

Component location, refrigerant flow, air flow, and wiring diagrams



Section C7

**System test and
fault diagnosis**

Lower quantity flap inoperative

Sheet 1 of 2

Fig. C48

Start

Switch on the engine. Set the ACU switch to DEFROST. At the lower quantity flap actuator, connect a 12 volt test lamp between the green/pink cable and earth. Does the lamp light?

NO

Verify that the orange/blue cable at the ACU switch is live and also that the green/pink cable from the diode block is live. If the green/pink is not live, the diode is faulty.

YES

Set the ACU switch to AUTO. Remove the sensor chain socket (servo moves to screen mode). Disconnect the fan delay thermostat. Is the test lamp extinguished?

NO

At the lower quantity relay, connect a test lamp between the blue/black cable and earth. Does the lamp light?

NO

An incorrect live feed to the actuator is being supplied from the orange/black cable at ACU switch or the green/pink cable at upper servo plug. Replace the appropriate faulty component. (ACU switch or servo).

YES

Remove the yellow/brown cable from the lower quantity relay. If the test lamp at the relay is extinguished there is an earth fault on the yellow/brown cable between relay and fan delay thermostat. If the test lamp remains lit, the lower quantity relay is faulty.

YES

After the previous instruction, did the actuator operate?

NO

Is there a live feed on the orange/white cable at the actuator?

NO

Go to sheet 2

YES

Set the ACU switch to DEFROST. Does the actuator operate?

NO

Connect an external earth cable between the black cable at the actuator and a good earth. If the actuator does not move it is faulty.

YES

The actuator is satisfactory.

During instructions 2 and 3, did the lower quantity flap fully open and fully close & did the microswitch operate?

YES

The flap and actuator are satisfactory.

Reconnect the sensor chain socket & connect the yellow/white cable to earth. (Servo moves to 'Facia' mode). Switch to AUTO. Does the test lamp light?

YES

2 faults or incorrect diagnosis.

NO

Adjust the flap and tighten the pinch-bolt so that the flap will fully open and fully close. Ensure that the microswitch operates correctly.

These are landmarks. They show which part of the system has been proved correct.


15% microswitch on upper servo faulty, check for live feed on green/pink cable at servo plug.




Lower quantity flap actuator right-hand drive cars



Lower quantity flap actuator left-hand drive cars




Location of sensor chain socket.




1 Hazard switch socket
2 A.C.U. sockets



Sensor chain socket.



Fan delay thermostat



15% microswitch on upper servo

Section C7

**System test and
fault diagnosis**

Lower quantity flap inoperative

Sheet 2 of 2

Fig. C48 continued

From sheet 1

Connect a test lamp between the blue/red cable at lower quantity relay and earth. Does the lamp light?

NO

YES

Connect the test lamp between the blue/white cable at the lower quantity relay & earth. Does the lamp light?

NO

Lower quantity relay faulty.

YES

At the diode block, connect a test lamp between the blue/white cable and earth. Does the lamp light?

YES

Faulty diode between blue/white and orange/white cables, replace diode block.

NO

Open circuit in blue/white cable between relay and diode block.


At the upper servo plug, connect a test lamp between the blue/green cable and earth. Does the lamp light?

NO

Servo is probably faulty. Refer to Servo Fault Diagnosis.

YES


Open circuit in blue/green cable between servo and ACU switch, open circuit in blue/red cable between ACU switch & lower quantity relay or ACU switch faulty. Test for live feed using test lamp.



1. Hazard switch socket
2. A.C.U. sockets



Diode board, left-hand drive cars, viewed with top roll removed.



Diode board, right-hand drive cars.

Section C7

**System test and
fault diagnosis**

Lower servo test and calibration procedure
Sheet 2 of 2
Fig. C53 continued

From sheet 1

On the test box, set the IND/VOLTS to VOLTS and CHECK VOLTS to Position 2. Record the voltmeter reading. Is it between 1.7 and 3.3 volts?

NO

Internal fault in servo. Renew servo and repeat the complete test procedure for both upper and lower servos.

YES

On the test box, set CHECK VOLTS to Position 3. Is the voltmeter reading within ± 0.2 volts of the reading recorded in CHECK VOLTS Position 2?

YES

On the test box, set the IND/VOLTS to IND and the RUN/SET switch to RUN. The lower servo should run from $43\% \pm 2\%$ to 0%. At the lower servo arm, release the upper nut sufficiently to allow the temperature blend flap rod to be pulled through the servo arm until it stops under light pressure. Hold the rod under light pressure and adjust the lower nut to contact the servo arm, then tighten nuts.

NO

Interchange servo modules and repeat checks at CHECK VOLTS Position 2 and 3. Are the readings within ± 0.2 volts?

NO

Upper servo module is also faulty. Renew both modules.

YES



The original servo module is faulty. Renew servo module.

Go back to * on sheet 1

These are landmarks. They show which part of the system has been proved correct.

The lower temperature blend flap is now correctly set

The lower servo and lower servo module are now proven to operate correctly from the test box. If a fault still exists, refer to the LOWER SENSOR CHAIN FAULT DIAGNOSIS



Workshop tools

RH 7792	Extractor pilot — Compressor pulley
RH 7794	Handle
RH 7796	Installing tool — Compressor pulley and bearing
RH 7798	Holding tool — Compressor clutch hub
RH 7799	Fitting tool — Compressor hub and drive plate
RH 7937	Adaptor — Schrader valve
RH 8741	Extractor — Compressor pulley
RH 8851	Test box — Automatic air conditioning system
RH 8948	Removal tool — EEVIR unit valve capsules